






Thanks for shopping with Jeco®

Isobel 7FT Aspen Clear Tree

SKU# CH-CT89 / 16010024



Part List:

A. Tree Top Qty: 1 	B. Tree Middle Qty: 1 	C. Tree Bottom Qty: 1 
D. Metal Tree Stand Qty: 1 	E. Thumb Screws Qty: 3 	

JECO

1-800-893-3006
Ontario, CA 91761

Made in China

If you have questions regarding this product, call
1-800-893-3006 Mon.-Fri. 9:00-5:00 PST
(California) and ask for our product specialists, or
e-mail: cs@jeco-inc.com


See many more products on the Internet!

www.jeco-inc.com


To Assemble:

Please read all the instruction and warnings before assembling.
Before you start to assemble your tree, choose a location near a wall outlet.
Make sure the tree stand is placed on a level surface.

Step 1: Carefully open the tree stand (D) and place the stand on a leveled surface. Take the bottom section (C) of the tree and insert it into the stand. Secure the bottom section of the tree to the stand by tightening the thumb screws (E) evenly.



Step 2: Take the middle section (B) of the tree and insert it into the bottom section (C) of the tree and make sure the trunk stays straight. Then take the top section (A) of the tree and insert it into the middle section (B) of the tree.




Step 4: Shape the branches to your preference by working from the bottom to the top. When shaping the branches start with tips farthest from the pole. One to the right, one to the left, and one at the center of the main stem, slightly upseep all branch tips for a uniform look.



Step 5: (For pre-lit trees only) Connect the light strings as per the color lables indicated in **Fig. A** and insert green lable plug into the wall outlet. Your entire tree should now be lit.

Fig.A-Tree and Light Assembly

***Electrical Rating For The Tree
(For Indoor Use)
1.7A 120V 60Hz**



Operation:

After the plugs are plugged into the wall outlet your entire tree should be lit. If some bulbs do not light, search for any loose plugs, broken, loose or missing bulbs that may have caused the problem. Replace bulbs promptly with replacement bulbs provided in order to maintain the performance and life expectancy of you tree.

Step 1: Connet the light strings of the tree together and plug the power cord into a wall outelt.

Step 2: If a bulb is blown, replace the faulty bulb following the diagram below. Spare bulbs are included for easy replacement..



WARNING-Risk of Fire and Electric Shock:

1. Read all instructions and warning tags included with this tree.
2. For Indoor Use.
3. Do not place near gas or electric heaters, radiators, fireplaces, or other similar sources of heat.
4. Place on a level, hard, flat surface; do not place where tree is likely floors or thick carpeting.
5. Do not use candles on tree.
6. After assembly and adding decorations, make sure the tree is stable. If stable, shift the weight of the decorations, and use support wires to walls and/or window frames (make sure they are secure also).
7. Do not overload extension cords or power strips, see ratings on those devices and check the rating labels on the tree for compatibility.
8. Do not install near fountains, bathtubs, sinks, pools or other areas of standing water.
9. Only use this product with extension cords rated for indoor use.

Care and Cleaning:

Step 1: Remove all ornaments and decorations.

Step 2: Unplug the cord from the wall and then unplug each section of the tree.

Step 3: Gently lift the tree top straight up to remove from the center section and fold all branches towards the pole.

Step 4: Carefully place all tree sections into a shipping box and tape it shut.

Step 5: Store your tree in a cool, dry place away from sunlight.