

Thanks for shopping with Jeco®

Birdhouse with Wind Spinner Fountain

SKU# FCL146 / 15030079



Parts List:






1-800-893-3006 Ontario, CA 91761 Made in China

If you have questions regarding this product, call 1-800-893-3006 Mon.-Fri. 9:00-5:00 PST (California) and ask for our product specialists, or e-mail: cs@jeco-inc.com
See many more products on the Internet!


www.jeco-inc.com

To Assemble:


Step 1: Carefully attach the pump (C) to the hose, making sure to place the pump in the center of the bottom barrel (B).




Step 2: Attach the top birdhouse (A) to the bottom part (B).




Step 3: Attach the metal wind spinner (D) to the bottom part (B).



Step 4: Fill the basin (B) with clean water, making sure the pump (C) is fully submerged. **Note:** The maximum water level should be approximately 1.2 inches below the top edge of the basin (B).




Step 5: Attach the plastic wheel (E) to the bottom basin (B).



Step 6: Finally, connect the plug of pump (C) to a GFCI outlet.

WARNING: Always disconnect the pump (C) before placing your hands in the water.



CARE AND MAINTENCE

| I | To eliminate the possibility of water damage to areas around the fountain, check for |
|---|---|
| | leaks and excessive splashing after the initial set up of the fountain. It is highly |
| | recommended this fountain be placed in an area where it cannot be damaged. |
| ı | Do not leave the fountain running for extended periods of time when no one is present |
| | to observe the performance. |
| ı | Check the area around the fountain on a regular basis to ensure there is no leakage. |
| ı | Do not attend to attempt to move fountain once filled with water. |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |